

## INSTALLATION INSTRUCTIONS FOR CONVECTOR HEATER GUARD

**Part Number: CG2N0003**

**PLEASE RETAIN THIS LEAFLET FOR FUTURE MAINTENANCE**

### CONVECTOR HEATER GUARD

The heater guard is designed for use with Consort CN2 and other convectors. Provision has been made for controls mounted on the side and the front of the unit, with cover plates supplied to restrict access to the controls via an M4 pan head Pozidrive screw.

### MOUNTING INSTRUCTIONS

1. Locate the template supplied centrally on the top of the wall mounted convector heater and mark the 2 top fixing holes. This will ensure that the guard is central and at the correct height.
2. Drill the 2 marked holes to suit No 8 wood screws and insert rawlplugs.
3. Fit and tighten screws until the heads are approximately 10 mm from wall.
4. The guard can now be located and 4 external fixing holes marked.
5. Remove guard and drill holes to suit No 8 wood screws and insert rawlplugs.
6. Locate guard and fix securely in place using 4 x No 8 wood screws.

