

CRXSLWIFI Wireless Controller - Mains-powered

The CRXSLWIFI wireless controller has WIFI capability which when being used, connects any RX or SL heaters to the Consort Connect app. The app provides complete heating control remotely, with programming and energy saving features, including the ability to view energy consumption statistics in the last day, week, month and year.

It includes an optional open/close window detection feature which reacts intelligently to temperature changes in the area or room, turning off the heating to save energy when it senses a sudden drop from an open window or door. It restarts once the window or door is shut. Settings for detection time and temperature can be customised in the setup menu.

- Mains-powered
- Slim design and wall recessing
- Compatible with all RX and SL heaters
- Quick and simple pairing to heaters
- Only works with 2.4GHz WiFi network
- Open window detection
 - Once enabled in the setup menu, the feature is fully automatic and doesn't require further intervention.
- Large backlit LCD display for easy reading
- Simple to set up and easy to programme
- Electronic lock is available on the controller and the app
- The Consort Connect app features a 4-digit pin code lock to prevent accidental or unauthorised changes to settings. Users can unlock it via the app or the CRXSLWIFI controller.
- Option to limit min/max temperature
- Fits onto standard double gang box
- Features and functions when being used with WiFi:
 - 5 operating modes: Manual, Frost protection, Fan, Boost & Automatic timer.
 - 15-minutes Boost feature providing maximum comfort quickly.
 - 7-day timer with 24 heating periods per day.
 - Ability to view energy consumption statistics on the app.
 - Open window tracking and response capability.
 - Comfort heat setting between 4°C to 35°C.
 - Setback temperatures can be used for frost protection or maintaining a minimum room temperature 4°C to 15°C.



Dimensions (mm):

Model No.	Height	Depth	Width
CRXSLWIFI	85	34	145

CRXSL Energy Saving Features

- Half heat when approaching target temperature for RX heaters only*
- Maintains temperature within 0.5°C
- Set temperature in 0.5 degrees increments

* Half heat feature does not apply to 0.5kW & 0.8kW heaters.