

MCBMS - Simple BMS Connection for CH heaters

- Offers two functions
 - 1) BMS error reporting
 - 2) External remote or boost switch connection
- MCBMS must be used in conjunction with a CHMC controller and CH heaters when used as a switch.
- Each system can have a maximum of 8 heaters.
- BMS error reporting works on all Consort heaters as long as they have an RJ45 connector.
- Green LED to show that the device is powered.
- Orange LED to show when a fault is detected in one of the heaters in the system.
- Remote switch connection for BMS, On/Off function or Boost.
- Boost function boosts the temperature for a set duration.

